


AISWatchMate[®] RX



You must connect the AISWatchMate to a GPS for alarms to function.

